



















CenterLine® 220



- ON / OFF, LIGAR / DESLIGAR, LIGAR / DESLIGAR, MARCHÉ / ARRET, EIN / AUS, AAN / UIT, HA / ПРОЧЬ
- Brightness, Brillo, Brilho, Éclairage, Helligkeit, Lichtsterkte, Яркость
- Contrast, Contraste, Contraste, Contraste, Kontrast, Contrast, Контраст
- Change Page, Cambie La Página, Mude A Página, Changez mode d'affichage, Ändern Sie Seite, Verander pagina, Следующая страница
- Decrease, Disminuir, Diminuir, Diminuer, Vermindern, Verminder, Уменьшение
- Increase, Aumentar, Aumentar, Augmenter, Erhöhen, Verhoog, Увеличение
- Guidance Mode, Patrón De la orientación, Padrão de Orientação, Mode de guidage, Führungsmodus, Begeleidingsmode, Метод руководства
- Swath Width, Ancho de la faixa, Largura da faixa, Largeur de travail, Arbeitsbreite, Werkbreedte, Рабочая ширина
- Return to Point, Vuelva al punto, Retorne ao ponto, Revenir au point, Zurück zu Punkt, Terug naar punt, Назад к пункту
- Mark A/B, Marque A/B, Marque A/B, Marquer A/B, A/B erstellen, Markeer A/B, A/B установить



CenterLine® 220



Mølhavevej 2
 9440 Aabybro
 Denmark
 Tel. +45 9696 2500 Fax +45 9696 2501
 www.teejet.com



CENTERLINE® 220
 USER GUIDE
 Guía Del Usuario
 Guia do Usuário
 Guide d'utilisateur
 Bedienanweisung
 Handleiding
 Руководство для пользователя

